#### AMADA MACHINE TOOLS AMERICA, INC.





THE VISION OF PRECISION

# Lineup of Grinders



#### Contents

	Amada Machine Tools America Amada Grinding Technology	1 2
OPTICAL GRINDERS		3
	GLS 150GL Optical Profile Grinder	4
	<b>DV1</b> Digital Profile Grinder	10
CNC HIGH-SPEED GRINDERS		23
	Meister G3 and Meister V3 High-Precision Forming Grinders	24
	Winstar SP Ultra-High Precision Forming Grinder	30
ROTARY GRINDERS		43
	SSR5 Rotary Surface Grinder	44
CNC SURFACE GRINDERS		49
	Techster 52 and Techster 52S High-Capacity, Multi-Purpose High-Speed Grinders	50
	<b>Techster 64 and Techster 64S</b> Saddle Type Precision Surface CNC Grinder	52
MID-SIZED CNC SURFACE GR	RINDERS	57
	Techster 84, 104, and 126 Column Type Precision Surface Grinders	58

# **Amada Machine Tools America**



With more than 70 years of industry experience, Amada Machine Tools America is committed to helping our customers deliver dependable service and top-quality work with exceptional grinding solutions.

Whether you need profile, forming, surface, or rotary grinding, we have the right solution for your specific needs.

Market-Leading Quality—We believe quality Proven Accuracy—We help you take your work begins with quality tools designed and built from the ground up to deliver outstand- customers' expectations. ing performance, time after time.

**Customer-Driven Innovation**—Every feature, function and configuration we offer has been developed to address the needs of our customers.

work to the next level and exceed your

**Reliable Productivity**—We understand productivity is the heart of your business, and we can help you optimize it in multiple ways.

## A History of Cutting-Edge **Manufacturing**

Since we began building profile grinders back in the 1940s under the Wasino name, our goals have always been to provide our customers with increased accuracy and productivity. Throughout our history, we've maintained our time-honored tradition of hand-fitting our grinders to deliver the ultimate in quality and precision.


And, as technology has evolved, we've embraced CNC automation as a core strength, improving throughput and helping new operators become productive more quickly.

Today, we are uniquely positioned to help you expand your capabilities and grow your business.

#### **Solutions Designed Around Customer Needs**

No two manufacturing needs are exactly alike. Finding the right solution means thoroughly understanding your objectives and configuring a solution to match them precisely. Our engineers bring decades of industry experience to help you achieve your specified goals with a process that fits—and enhances—your workflow.

#### TECHNOLOGIES OF AMADA



Amada Grinding Technology 1

# **Amada Grinding Technology**



When the tightest tolerances and accurate repeatability matter, Amada is a world leader in optical profile grinding and high-precision surface and profile work. Suppliers to high-tech electronics and semiconductor manufacturers have trusted Amada grinders for years to deliver the flexibility, precision and productivity they need to stay ahead in a rapidly changing industry.

- Integrated measuring technology
- Award-winning innovation
- Maximum accuracy optimized through use of the most modern construction/design
- High speed for increased efficiency
- Integrated automation for higher efficiency
- Automatic swiveling grinding head during the grinding cycle
- External programming software to optimize part production
- · Modular construction for versatile and economic specification

#### **Engineered to Perform**

**Optimum Balance Supports High-Reciprocating Grinding**—As a pioneer in high-reciprocating grinding and processing, we have achieved a superb, dynamic balance between the machine and the grindstone to deliver superior performance with the widest range of work materials.

#### **High-Quality Grinding that Exceeds**

**Specifications**—The accuracy of our grinding and processing work goes beyond simply measuring RZ to deliver mark-less and sharpedge mirror finishes.

Reliable, High-Rigidity Structure—The form of the machine has been developed by advanced three-dimensional design and finalized through a comprehensive series of demonstration tests to create highdimensional rigidity.

**Consistent Repeatability**—Through superior design and meticulous assembly practices, Amada grinders are engineered to account for thermal displacement, ensuring maximum accuracy throughout the working process.

#### Advanced, Easy-to-Use CNC Software—Every Amada grinder has dedicated software to

allow your operators to take full advantage of each machine's capabilities.

#### From Surface Grinding to Molding to **Profile**—Amada's exclusive WAPS platform gives you complete control of all forming processes—rough, semi-finish, and finish processing. It also prepares charts for optical

profile grinding and data for profile dressing.

Original Measurement Technology on **Equipment**—Save time and steps while ensuring maximum accuracy with built-in measurement technology.



#### **GRINDING TECHNOLOGY**

# **Optical Grinders**

Amada's optical grinders have set new standards in machining high-precision components for tool and die, mold shops, and the industry in general. With an uncompromising approach to manufacturing standards and extensive engineering expertise, we have helped our customers expand their capabilities and improve their productivity.

**GLS 150GL GLS 150GL** OPTICAL PROFILE GRINDER



# **GLS 150GL Optical Profile Grinder**

It took a fresh perspective—and 70 years of industry expertise to deliver an advanced profile grinder with a light touch. Whether you're making mold slides, machine parts, punches and dies, or core pins, the GLS 150GL delivers the precision and efficiency you need to meet your customers' specifications.







Optional TC-20 High-Precision and High-Speed Spindle



Ultra-High Speed and High-Precision Wheel Heads

#### **GLS 150GL Features**

#### High-Accuracy/High-Definition Projector—

A redesigned lighting system increases brightness by approximately 15% compared to existing machines.

**High-Reciprocating and High-Accuracy** Wheel Heads—High-accuracy and highresolution optical scales ensure ultra-precise feeding while an extremely rigid frame and a stable, balanced structure deliver high reciprocation rates of 400/min. Reciprocation

Spindle (TC-20)—The TC-20 spindle provides stroke length is 6.1" (155mm). An oil-cooled inverter (allowing ±0.1°C control) is mounted as standard equipment.

**Gravity Center Design Bed**—The newly developed bed features an optimized allocation of jack bolts and ribbing, solving flexure at the center and supporting high static accuracy.

**User-Friendly Controls**—A large 10.4" screen LCD panel and easy-to-use software improve operability and support high-accuracy processing.

**Shortened Setup Time**—The positioning speed of each spindle axis is increased for improved efficiency, including their fastforward speed (59"/min., 1,500 mm/min.) and table up-and-down speed (11.8"/min., 300 mm/min.). Dedicated software also enables automatic work setup.

**Space-Saving Design**—The GLS 150GL is approximately 25% smaller than the previous model, thanks to optimized design based on structural analysis.

#### High-Precision and High-Rigidity Spindle

(TS-6)—The standard low-speed, high-power spindle delivers 6,000 RPM and supports a large-diameter grinding wheel.

Optional High-Precision and High-Speed high speed (20,000 RPM) and precision with low heat generation.


Newly Designed Ultra-High Speed and **High-Precision Wheel Heads**—Mirror surface finishing can be achieved in less time, and the 6.1" (155 mm) stroke accommodates a wide range of workpieces.

#### **Tool Grinding Combining NC Swiveling**

**Axis**—The edge sensor and three-axis teaching function make grinding of blade edges with lead easy.

Coping with Wet Grinding—The newly designed wet grinding cover allows for bulk flow wet grinding of hard workpieces while reducing heat generation and wear on the grinding wheel.





Shoulder Punch and Die



Core Pins

Amada Lineup of Grinders Optical Grinders 5 GLS 150GL OPTICAL PROFILE GRINDER







Ultra-High Speed and Coping with Wet Grinding

Hand Wheels


Using a High-Definition Projector

Control Panel

# Optical Profile Grinding to Meet Your Highest Quality and Operation Demands

Operators can easily deliver ultra-precise machining with in-process optical inspection via the projector. This unique technology is what makes the GLS 150GL so popular. Contour accuracies down to  $1\mu m$  can be achieved, and the operator can select the most suitable method of operation—manual, NC-assisted, or CNC controlled with up to three-axis interpolation. Using the teach-in playback function, even grinding wheel wear can be easily compensated.

- High-resolution projector with magnifying glass
- High-capacity and friendly FANUC CNC unit
- Fast-stroke system with up to 400 SPM
- Teach-in playback system/macro/external programming
- Built-in coolant systems for maximum accuracy (option)
- Optional C axis for three-axis interpolation




Teach-in Playback System

Cutting Tools

Shoulder Punch and Die

# Examples of Mirrored Surface Polishing


Designed to deliver extreme precision, the GLS 150GL can consistently produce outstanding surface finishes to the tightest tolerances.



Grinding Surface Finish



Wheel Head Design Based On Structure Analysis



Sample Piece

Material: G5 (Cemented) Grinding Time: (Finish) 18 min Reciprocation Stroke: 13 mm (Grinding Accuracy) ±0.001 mm

GLS 150GL OPTICAL PROFILE GRINDER







Auto Balancer

On-Board R-Form Dresser MRD-180

Screen Loupe

#### PROGRAMMING OF THE GLS 150GL

The GLS 150GL offers operators a choice of operating methods to match their desired way of control or operating skills.

- Manual operation using the hand wheels
- Using the teach-in playback system
- Using standard cycles (macro programming)
- Using external programming software



Taper Interpolation



External Programming

## **Options for Specific Applications**

**Auto Balancer**—This measuring instrument is used to adjust the balance of the wheel and spindle as a single unit. Perfect balancing improves the ground surface roughness.

#### On-Board R-Form Dresser MRD-180-

This table-mount dresser is used for reforming the radius of the profiling wheel, and it's easily programmed by the operator.

Screen Loupe (P.A.T.)—The screen loupe is used to verify the work profile by partially magnifying its enlarged image and the chart for comparison. As it fits into the screen frame, both handles can be operated at the same time. Loupes are available in 2.2x and 4x magnification.



#### Circular Grinding Attachment—

This attachment is used for grinding cylindrical parts/tools, etc.

- Swing: Ø7.87" (200 mm)
- Distance between centers: 7.87" (200 mm)
- Adaptable to dead or live centers



# Automatic Work Swivel Unit (mounts to Ø1.26" [32 mm] hole)—

The automatic work swivel unit can be set to an indexable angle or to continuous feed applications. One setting can provide complete periphery processing of the work.

## **Machine Specifications**

	Working surface	e (L x W)	15.7" x 9.8" (400 x 250 mm)		
		Traverse feed	11.8" (300 mm)		
TABLE	Torrigh	Cross feed	5.9" (150 mm)		
	Travel	Minimum input increment	0.000010" (0.0001 mm)		
		Position detection system	Semi-closed loop		
	Reciprocating s	lide stroke	0~6.1" (0~155 mm)		
	Reciprocation s	peed	30~400* SPM		
		Traverse feed	7.87" (200 mm)		
	T 1	Cross feed	5.9" (150 mm)		
WHEEL HEAD	Travel	Minimum input increment	0.000010" (0.0001 mm)		
		Position detection system	Full-closed loop		
	D 11 6 1	Radial direction of wheel	-2~+20 °		
	Relief angle	Axial direction of wheel	±15°		
	Swivel slide sw	iveling angle	±15°		
PROJECTOR	Screen size (W x H)		21.25" x 16.5" (540 x 420 mm)		
PROJECTOR	Magnification		20x, 50x		
	Size (OD x width x bore)		Ø4.72"~7.08" x 0.12"~0.39" x Ø1.25" (Ø120~180 x 3~10 x Ø31.75 mm)		
WHEEL SPINDLE	Wheel spindle speed		1000~6000 RPM (TS-6)		
	Motor capacity		2 HP~4 P(1.5~4 kW-P)		
FLOOR SPACE (WID	TH X DEPTH)		69.29" x 68.89" (1760 x 1750 mm)		
MACHINE WEIGHT			9900 lb (4500 kg)		
POWER CAPACITY			18 kVA		
	CNC unit model		FANUC		
	Display		10.4" (264 mm)		
CNC CONTROLLER	Manual handle		2 : X, Y (Z, V)		
	Pitch error mod	ification	Standard		
	Number of axes		4 axis (simultaneous 2 axis)		

<sup>\*</sup>Reciprocation process speed is changed by the time of reciprocation process.



Take your optical profile grinding to the next level with a compact, chartless, and fully automated third-generation profile grinder. Available with five-axis control (for superior surface finishing), the DV1 can also be specified with 16 pallet stations for automatically changing out workpieces and grinding wheels, giving you the ultimate in truly "hands-off" productivity in one compact, user-friendly package.





Ultra-Precision Shoulder Punches

CCD Camera System

#### **DV1 Features**

Compact, Fully Enclosed Design—A full cover improves operational safety and environmental performance while still allowing easy access for operators.

Four-Sided Grinding for Maximum **Efficiency**—The CNC rotary table allows for full periphery processing with one chucking.

Processing—The fully automated DV1 incorporates a state-of-the-art CCD camera system for automatic, on-machine measurement and compensation. That means improved precision and consistency on every job.

**Process Stability**—Through completely unmanned and chartless finish processing, variations in processing standards are remarkably reduced.

Verify Very Small, Fine Shapes—The automatic inspection system can qualify very small shapes of 1-degree angles or less, which cannot be easily measured with a projector.


**Ideally Suited for Precision Carbide Punch Grinding**—The DV1 can consistently deliver inside form tolerances of 0.0001".

**Automatic Compensation Grinding System**— Optical resolution of 10x and monitor resolution of 350x is standard equipment on the DV1. With the proven CCD camera image processing technology, full automation is achieved throughout measurement and automatic program editing.

10 Amada Lineup of Grinders Optical Grinders 11 **DV1** DIGITAL PROFILE GRINDER

## **Comparing Optical Grinding to Digital Grinding**

If you use two machines for one worker, our optical profile grinder GLS 150GL requires manual form measurement and program correction, resulting in idle time for a machine. In contrast, the DV1 can perform this task automatically, resulting in shorter lead times and improved productivity.





# The Leader in Profile Grinding Goes Digital

Structural analysis, including 3D design, provides rigidity and compact design for the DV1. LCD displays and CCD cameras have replaced the traditional projection systems, and Mylar charts are replaced by CAD-based digital profiles. The net result is that program creation can now be based on actual digital data. Also, because the system is chartless, there's no need for a plotter. In addition, the original image teaching program function uses the CCD camera without a projector (as standard equipment), allowing for chartless instrumentation. This also allows the use of full-enclosure guards for high-performance design characteristics without any compromise in basic work efficiency.

**DV1** DIGITAL PROFILE GRINDER **DV1** DIGITAL PROFILE GRINDER





CNC Rotary Table

Optional Full Automation Available

Operation Panel Screen

#### **Productivity Made Easy**

**CNC Rotary Table Allows Four-Sided** 

**Grinding for Maximum Efficiency**—With a CNC rotary table as standard equipment, the DVI is capable of full periphery processing with one chucking. Multiple wheel operations capable of running completely unattended. for roughing all sides of the workpiece can be completed—completely unattended—before changing the wheel for finishing.

Easy-to-Use PC NC Interface—The PC NC operation software, accessed through a 12inch color touch panel, significantly improves operability. The new layout of the operation panel organizes the function for both ease of use and clarity. Optimum usability makes this powerful grinder technology a pleasure to operate.


#### Optional Full Automation Available—

With the addition of articulated robots for automated workpiece exchanges and wheel changes on the ATC spindle, the DV1 is


#### **Automation that Drives Accuracy**

The implementation of CCD camera systems puts the DV1 in a new class of grinding technology.


Automatic measurement of workpiece form with automatic re-grinding ensures repeatable precision.



**2** | The DV1 can process ultra-small workpieces below an angle of 0.04" (1 mm), which is difficult to measure with a projector. In addition, the edge compensation function ensures consistency of inspection.




Automated CCD camera measurement eliminates subjective manual inspection, dramatically reducing variations in processing quality.



Measurement data can be output, providing documented part qualification.

Grinding wheel form measurement can be performed.

**DV1** DIGITAL PROFILE GRINDER



Full Automation for Roughing and Finishing Operations

# Fully Automated Part Production with Articulated Robot and Stocker


Through automatic wheel changing, rough and finish operations are seamless and can be conducted completely unattended. The ATC spindle automatically clamps the necessary wheels to fully process workpieces, unattended. Measurement software for flat (1A1) grinding wheels automatically qualifies the wheel width/position, and an integrated rotary dresser provides peripheral, side, and corner radius dressing in flat wheels for semi-finish operations. Rough plunge cycles speed throughput.




Five-Axis Controls For High-Quality Surface Finish

# **Uncompromising Machine Design** for High-Precision Form Processing

**Five-Axis Controls for High-Quality Surface Finish**—The DV1 employs a crank-motion elevating stand to achieve superior surface finish. The TC-20 spindle (developed by Amada for 20,000 RPM performance) supports high precision and high speed when creating small and medium shoulders. Integrated front and side clearance ensures angles that satisfy die specifications.





Grinding Step Profile

Surface Finish Measurement Data

## **Precision in Part Processing**

An ultra-hard workpiece 0.1" (2.5 mm) thick is precision-ground to within 1 $\mu$ m. Test piece is five steps of 10 $\mu$ m, as pictured, with grinding, measurement and compensated re-grind. A work surface finish of Rz0.16 $\mu$ m is achieved, showcasing the DV1's ability to produce "light" surface finishes.

# 10μm step grinding (5 steps) with automatic compensated re-grind

- Processing material: ultra-hard (G5 equivalent)
- Main spindle rotation speed: 12,000 RPM
- Reciprocation speed: 120 RPM
- Grinding wheel: TWD700R2
- Grindstone size: Ø3" x Ø0.87"
   (Ø75 x Ø22.23)
- Single V150: R0.05

#### Straight processing (X-axis shift)

- Processing material: ultra-hard (G5 equivalent)
- Main spindle rotation speed: 12,000 RPM
- Reciprocation speed: 100 RPM
- Depth of cut: 0.0002" (0.005 mm)
- Feed speed: 0.04"/min. (1.0 mm/min.)
- Measuring machine: surface finish measuring instrument (Taylor Hobson)
- Grinding wheel: TWD700R2
- Grindstone size: Ø3" x Ø0.87" (Ø75 x Ø22.23)
- Single V150: R0.05
- Wheel dressing device: MRD-180 dress after ~10 min. grinding time
- Dressing time: 5 min. (finish only)

**DV1** DIGITAL PROFILE GRINDER **DV1** DIGITAL PROFILE GRINDER





Image-Based Teach and Playback

Chartless Measurement

state Fron Count

Automatic Workpiece Form Measurement/ Compensation Processing



Grinding Wheel Position and Shape Measurement

# Custom Software and Craftsmanship in a Digital World

The new operation panel is designed for ease of use, and the control system allows intuitive navigation through all the powerful functions.

**FANUC Series 32i-B**—Five-axis control specification:

- Table X, Y
- Headstock up/down (W)
- Table up/down (Z)
- Workpiece pivot (B)





12-inch Color LCD Touch Panel (top) USB Port (above) Operation Panel (right)



#### Software

The custom software on the DV1 is designed for maximum productivity.

#### Image-Based Teach and Playback—

Image-based teach and playback software can **Compensation Processing**—After the grind create programs visually using monitor images operation is finished, the standard position of digital profiles, providing digital accuracy instead of projector-and-chart methods. Additionally, using digital profiles enables automatic measurement of the workpiece profile by measuring the CCD camera image of the workiece against the actual digital image.

Image teaching provides an actual, wheelbased profile by capturing digital images of the wheel profile. Then the wheel image is used to "teach" the wheel path against the digital workpiece profile. Actual teaching is done by manipulating the handle.

Chartless Measurement—CAD data (DXF) is loaded and, based on the processing data, the position of the workpiece image is set. When the manual handle is turned, the workpiece image moves. Similarly, by moving the cursor on the NC screen, the workpiece the difference.

**Automatic Workpiece Form Measurement/** is confirmed and measurements are made to determine the deviation from the standard. This is done automatically—no operator intervention or programming is required.

At the time of measurement, multiple points are simultaneously inspected and large deviations from the standard are disregarded. The measured image area is as small as 0.019" (0.5 mm). In order to measure areas less than 1µm, the number of pixels and dots is set.

**Grinding Wheel Position and Shape** Measurement—The on-board dresser unit re-trues the leading edge radius of the grinding wheel. The shape of the grinding wheel is plunged into the dummy workpiece fixtured to the table. Through the dummy, the profile of the grindstone radius is measured image moves, and the software can determine at multiple points, and determined by CCM calculations. Taking measurements at multiple points minimizes errors. This procedure automatically qualifies both the wheel radius and wheel position, greatly facilitating the setup process.

18 Amada Lineup of Grinders Optical Grinders 19 **DV1** DIGITAL PROFILE GRINDER **DV1** DIGITAL PROFILE GRINDER

# **Machine Specifications**

	Screen size			12" LCD (CCD view range 0.5 x 0.4 mm)	
PROJECTOR	Magnification			Optical magnification x10/monitor magnification x350	
	Lighting			Tapering lighting 150 W	
	Working surfac	e		4.5" (Ø115 mm) (round table)	
	Distance from t	he table top to focus բ	point	7.8" (200 mm)	
	Maximum loadi	ng weight		44 lb. (20 kg) (workpiece + fixture + chuck)	
			Traverse feed (X axis)	11.8" (300 mm)	
		Travel	Cross feed (Y axis)	9.8" (250 mm)	
			Vertical feed (Z axis)	3.1" (80 mm)	
		Feedrate	Rapid traverse (GOO)	XY: 78"/min, Z: 19.6"/min (XY: 2000 mm/min, Z: 500 mm/min)	
	Linear axis	reediate	Linear interpolation (GO1)	XY: 0.0004~39"/min (XY: 0.1~1000 mm/min, Z: 500 mm/min)	
		Jog feed		XY: 78"/min (2000 mm/min), Z: 19.6"/min (500 mm/min)	
TABLE		Minimun input increment		0.000010" (0.0001 mm)	
		Position detection/ scale resolution	X and Y axes	Full-closed/0.05 μm	
			Z axis	Semi-closed	
		Travel		360°	
	Rotary axis B		Rapid traverse (GOO)	1000°/min	
		Feedrate	Linear interpolation (G01)	0.1~1000°/min	
		Jog feed		1000°/min	
		Minimun input incr	ement	(0.0001°)	
		Position detection/	scale resolution	Full-closed/±5°	
	Wheel size (out	er diameter x width x	hole diameter)	Ø2.5"~3.9" x 0.15"~0.25" x 0.875" (Ø65~100 x 4~6 x Ø22.23 mm	
WHEEL SPINDLE	Spindle nose			Ø1.0" (Ø25.4 mm) 1/4 taper	
JI INDEL	Spindle speed			2000~20000 min <sup>-1</sup> (TC-20)	
		Reciprocating slide	stroke (W axis)	0 - 3.14" (0~80*1 mm)	
	Reciprocating axis	Drive system		Crank	
WHEEL HEAD		Reciprocation spee	d	1.18"~ $15.7$ " (30~400 mm) (in case of 10st)* <sup>2</sup>	
	Relief angle	Travol	Radial relief angle (V axis)	-1~2° (manual operation)	
	netiel dilgie	Travel	Axial relief angle (A axis)	±3° (manual operation)	

	Wheel spindle	2 HP~4P (1.5~4 kW-P) (TC-20)	
	X/Y axes	1 HP (0.75 kW)	
MOTOR	Z axis	.67 HP (0.5 kW)	
MOTOR	B axis	.06 HP (0.05 kW)	
	Reciprocating axis (W axis)	2.5 HP (1.8 kW)	
	Automatic lubrication	4 W	
POWER CAPACITY		13 kVA	
MACHINE SIZE (WIDTH X DEPTH X HEIGHT)		64" x 93" x 67" (1630 x 2370 x 1717 mm)	
MACHINE WEIGHT		8800 lb (4000 kg)	

<sup>\*1</sup> Length that can be processed will vary depending on the setting of relief angle.
\*2 There is limitation depending on the reciprocation stroke.

# **NC Control Specifications**

CONTROL UNIT M	ODEL	FANUC SERIES 180i-MB	
NUMBER OF CONTROL AXES	5-axis control specification	Table X, Y; table vertical Z; reciprocation W; workpiece rotary B	
	12" color LCD (touch panel)	Manual reference return	
	PC NC (O/S Windows XP)	Memory-type pitch error compensation	
	CNC screen display function	Feedrate override 0 to 200%	
	Wheel spindle infinitely variable-speed drive (inverter control)	Tape memory 40m (16kB)	
	Simple S command (7-speed)	Registerable programs 63	
STANDARD	Reciprocation 20-speed (servo control)	Total tool offset pairs 32	
FUNCTIONS	Circuit breaker (30mA)	Tool length compensation	
	Auto power off	Rapid speed override	
	AC100V outlet (2P-1 outlet)	Warm-up timer (daily timer)	
	3 manual handles (5-spindle control specification: common to X axis, Y axis, Z/B axis)	Memory card I/O	
	Handle magnification ratio Off, x1, x10, x100	Table setup function	
	Additional memory (80, 160, 320, 640, 1280m)	Run hour and parts count display	
	Additional registerable programs (125, 200, 400)	Cycle time stamp function	
OPTIONAL	Additional tool offset pairs (64, 99, 200, 400)	Automatic corner override	
UNCTIONS	Weekly timer		
	I/O interface		
	LAN connection (additional Ethernet function/connector for the PC part) *3		

<sup>\*3</sup> Device for LAN connection is added. The network connection for the PC part should be set by customer.


20 Amada Lineup of Grinders Optical Grinders 21

## **Software**

DV1 SOFTWARE	(APPLICATION FOR PC)	CONVERSATIONAL MICROSOFTWARE, ETC.
	Image teaching playback	Wheel data recording function
	Chartless measurement	Fixture recording function
	Processing simulation display	Simple S command (7-speed)
STANDARD FUNCTIONS	Workpiece standard measurement	Warm-up setting
	Processing actual performance display	
	Wheel position measurement (wheel transcription form measure	
	Automatic workpiece form measurement/correction processing so	oftware
	Rough grinding cycle	Taper interpolation
OPTIONAL FUNCTIONS	R-forming dress software	Simple circular interpolation
	Outside auto programing software ASSIST DV*4	Repeat cycle
		Run hour display function

Coolant Tank (per application)

# Floor Layout DV1 Stand-Alone Specification



# **Multi-Axis Robot Stocker Specification**

ROBOT	Robot	Manufacturer: FANUC	
	Number of controlled axes	6 axes	
	Maximum travel	35" (892 mm)	
	Maximum delivery weight	11 lb (5 kg)	Including robot hand
	Machine weight	63 lb (29 kg)	
STOCKER	Maximum number of stocked pallets	12 pieces	4 pallet x 3
	Maximum number of stocked wheel flanges	4 pieces	4 tools x 1
	Maximum workpiece size	4.5" x 3.5" (Ø115 mm x 90 mm) from pallet top surface	Pallet diameter 3.14" (Ø80 mm) is available
	Maximum wheel size	Ø2.9"~3.3" x 0.15"~0.23" (Ø75 mm~85 mm x 4 mm to 6 mm)	

<sup>\*4</sup> Not compatible with WAPS WIN.

# **CNC** Grinders

Amada's user-friendly software makes numeric control easy for operators with a wide range of experience. Coupled with the exceptional precision these machines deliver, Amada CNC grinders can help your business thrive.

**Meister G3 and V3** 

#### Meister G3 and V3 HIGH-PRECISION FORMING GRINDERS






# Meister G3 and Meister V3 **High-Precision Forming Grinders**

The Meister series of grinders offers outstanding versatility for every use—from simple to complex grinding tasks.

Steel, carbide, ceramics, and other materials can be ground in manual mode or in CNC mode. The machines come equipped with dressing and continuous path grinding technology and can be used for surface and profile grinding.







Core Pin Parts

Contour Grinding

Contour Grinding

## The Universally Recognized Masterpieces

precision surface and profile grinding with a measures the workpiece. Residual grinding fast-stroke mechanism. Advanced standard equipment includes CNC units, high-precision and the machine will repeat the grinding dressing and continuous path grinding technology for Y and X axes, spindle and hydraulic cooling, ceramic spindle bearings, and safely. And, the touch probe can now and full enclosures.

The control units of the Meister Series grinders offer optimum operability. Sophisticated macros make programming extremely convenient, even for inexperienced CNC users.

The Meister G3 and Meister V3 deliver ultra- A touch probe mounted on the grinding head allowances are automatically calculated cycle in unattended operation until the finish dimension has been reached—quickly determine the start position of the grinding wheel on the workpiece.

## **Four-Fold Increase in Productivity**

By way of direct comparison, users analyzed the machining time for a pair of mold and die parts made of carbide. Thanks to the convenient programming of the Amada grinding software and the fast-stroke mechanism, time savings of 75% can be reached compared to a CNC profile grinding machine.

24 Amada Lineup of Grinders CNC Grinders 25 Meister G3 and V3 HIGH-PRECISION FORMING GRINDERS

Meister G3 and V3 HIGH-PRECISION FORMING GRINDERS





Automatic Measurement Equipment

Ultra-Precision Parts

Mold Tool Parts

#### Meister G3 and V3 Features

- Grinding area
- Meister V3: 6" x 14" (152 mm x 355 mm)
- Meister G3: 8" x 16" (203 mm x 406 mm)
- High-quality equipment for surface, plunge-cut, and continuous path grinding as well as dressing
- Fast-stroke system
- Spindle available with ceramic bearings and 8,000 RPM capacity (option)

- High-resolution measuring systems
- Contour dressing and contour grinding with external programming software
- Built-in touch probe technology
- Three separate hand wheels for easy setup and manual operation
- Built-in coolant system for increased thermal stability

Vertical Feed System—The column has a symmetrical structure to minimize thermal deformation and is covered with heat-insulating materials for protection against changes in temperature and other environmental factors.

The fully enclosed loop feedback system with the linear scale of  $0.05\mu m$  resolution is standard for the Meister G3 (optional for others).

**Wheel Spindle**—The 3 HP (2.2 kW) spindle motor and inverter is standard on all models.

The spindle cooling system with oil color  $(\pm 1^{\circ}C)$  is standard on the Meister G3 (optional for others).

**Table**—The table features "V-V" slideways for exceptional straightness and features a servovalve-controlled transverse drive system with teaching function.


The Meister V3 features V-flat slideways with hollow runners for high speed and high accuracy.

**Bed**—The position of the jack bolts and ribs on the bed are optimized to support high-speed table reciprocation.

**New Model Control/Operation Panel**—The space-saving control panel with original software can improve machining efficiency.

#### RAPID RECIPROCATION TABLE

Meister Series grinders support reciprocation speeds two to three times faster than any former model, greatly improving machining efficiency.





# PROVISIONS TO PREVENT THERMAL DISPLACEMENT




The hydraulic unit is isolated from the main body and the hydraulic oil temperature is maintained at ±1°C by the built-in oil temperature controller.

Meister G3 and V3 HIGH-PRECISION FORMING GRINDERS Meister G3 and V3 HIGH-PRECISION FORMING GRINDERS







Pattern Grinding Contour Grinding

# **Original Software**

The software of Meister G3 and V3 grinders enables your operators to become productive be implemented by inputting the graphic without having to know complex NC programming.

Pattern Grinding—Complex shapes can be processed easily by combining five patterns. The combination of plunge and traverse options makes selecting the appropriate processing easy.

**Contour Grinding**—Molding grinding can data of arbitrary shapes. Rough grinding by plunge grinding can also be implemented, and the created data can be saved in the NC program area.

Pattern Dressing

Pattern Dressing—By inputting the dimensions required for the basic shape on the screen, the grindstones perform the molding using a simple profile dresser, NC profile dresser, or high-speed wafer dresser. The grindstones can also perform the molding during processing and interrupt dressing.

## **Machine Specifications**

			MEISTER G3	MEISTER V3	
	Table working	surface (L x W)	21.6" x 7.8" (550 mm x 200 mm)	17.7" x 5.9" (450 mm x 150 mm)	
CAPACITY	Max. longitud	inal travel	23.6" (600 mm)	19.6" (500 mm)	
	Max. cross tra	vel	9.8" (250 mm)	7.8" (200 mm)	
	Spindle center	r height from table	15.7" (400 mm)	15.7" (400 mm)	
	Standard chuc	k size (L x W x H)	15.7" x 7.8" x 3.9" (400 mm x 200 mm x 100 mm)	13.7" x 5.9" x 3.9" (350 mm x 150 mm x 100)	
TRAVEL	Longitudinal f	eed	3~131 ft/min*		
INAVEL	Max. no. of red	ciprocation (15 mm stroke)	250 min <sup>-1</sup> *	250 min1*	
	Rapid cross fe	ed (jog)	0~1312 ft/min, 164	Off/min, 3280 ff/min	
	Handle food	Per rev.	0.0004", 0.004", 0.04", 0.15" (	0.01 mm, 0.1 mm, 1.0 mm, 4.0 mm)	
SADDLE	Handle feed	Per grad.	0.000004", 0.00004", 0.0004", 0.0015"	(0.0001 mm, 0.001 mm, 0.01 mm, 0.04 mm)	
	Minimum input increment		0.000010" (0.0001 mm)		
	Position detection system		Glass scale/0.05µm		
	Rapid wheel head feed (jog)		3.9"/min, 39"/min (100 mm/min, 1000 mm/min) (2 steps)		
	Handla fand	Per rev.	0.0004", 0.004", 0.04", 0.15" (	0.01 mm, 0.1 mm, 1.0 mm, 4.0 mm)	
WHEEL HEAD	Handle feed	Per grad.	0.000004", 0.00004", 0.0004", 0.0015"	(0.0001 mm, 0.001 mm, 0.01 mm, 0.04 mm)	
IILAD	Minimum inpu	it increment	0.000010" (0.0001 mm)		
	Position detection system		Linear scale 0.05 μm (standard)	Linear scale 0.05 μm (OP)	
	Size (OD x wid	lth x bore)	Ø8" x 0.25"~1" x Ø1.25'	" (Ø205 mm x 6.4 mm~25 mm x Ø31.75 mm)	
WHEEL SPINDLE	Wheel spindle	speed		500 min <sup>-1</sup> ~5000 min <sup>-1</sup>	
J. INDLL	Motor requirement			3 HP~2 P(22~2 kW-P)	
NC CONTROL AXIS				Simultaneously 2 axis	
FLOOR SPAC	CE (W X L X H)		105" x 80" x 74" (2670 mm x 2040 mm x 1900mm)	74" x 58" x 74" (1880 mm x 1475 mm x 1900mm)	
MACHINE NET WEIGHT			5280 lb (2400 kg)	4840 lb (2200 kg)	

<sup>\*</sup> The table speed depends on work load on the table.

28 Amada Lineup of Grinders CNC Grinders 29

# **Winstar and Winstar SP**

#### Winstar and Winstar SP ultra-high precision forming grinders






The Winstar SP was specifically designed for users who push their demands for quality, dimensional accuracy, and flatness to the limits of technical feasibility.




NC Index Magnetic Chuck



High-Precision Rotary Dresser



NC Profile Dresse



Micro Pitch Grinding (100 Slots), Height: 0.002" (0.05 mm) P 0.01" (0.3 mm)



**Solutions for Today's Grinding Needs** 


With a stable platform, reduced thermal displacement, and a space-saving full enclosure, the Winstar SP delivers outstanding repeatability. It also delivers short lead times and the unmatched grinding precision required in all technology-driven markets, including medical, semiconductor, and electronics.

Air Vent Grinding



Core Pin Parts

Winstar and Winstar SP ultra-high precision forming grinders Winstar and Winstar SP ultra-HIGH PRECISION FORMING GRINDERS











Proprietary Column Type

Ultra-Low Vibration Spindle Motor

Specifications Guarantee High Productivity

NC Swivel Rotary Dresser

Twin Dresser

Vertical Rotary Dresser

## **Winstar Ultra-High Precision Forming Grinder**

One of our best-selling forming grinders, the Winstar features an ultra-low vibration, oilcooled spindle motor that delivers mirror-surface finishing for a wide range of applications.

**Proprietary Column Type, Three-Plane Independent Structure**—The Winstar's foundation is a T-bed with an elongated slide and column base. High static accuracy is ensured through an independent moving column design that provides excellent operability. In addition, the V-V slideway is fully supported, eliminating overhang and maintaining superior straightness accuracy.

**Table Reciprocating Specifications Guarantee High Productivity**—The Winstar uses a high-speed servo valve for high-speed stroking. At a 0.59" (15 mm) stroke, it can achieve 200 SPM inverse velocity. All series models boast high stroke reversal accuracy for stop grinding and can supply accurate longitudinal processing.

#### Features for a Wide Range of Grinding Needs

NC Swivel Rotary Dresser—The swivel rotary Automatic Measurement System (Touch dresser achieves high-precision form dressing **Sensor)**—The touch sensor automatically by means of three-axis simultaneous control performs measurements after grinding to with "normal" position dress capability. Together, they provide a leap in wheelforming accuracy, from taper to straight, and re-grind surfaces when measurements are radius forming. High-speed diamond disk dressing also greatly reduces inaccuracies due to diamond wear.

Twin Dresser TD-100—Previously, thin wheel dressing with a conventional wheel required a high degree of skill. But, by using the TD-100, dressing efficiency has made a great leap forward. Through the use of new, thin grinding wheels, forming widths of 0.0019" (0.05 mm) can be done by operators of any skill level.

#### **Vertical Rotary Dresser VRD-125**—A

motorized rotary dresser with a high-rigidity spindle delivers high-performance truing. Dressing can be performed on diamond and CBN wheels.

given dimensions within a canned cycle, enabling the machine to automatically out of tolerance. Measurement resolution is 0.05μm (0.000002"). and it also supports multiple workpiece measurement. Automatic workpiece approach setting is an optional

#### High-Speed Spindle 10,000 min<sup>-1</sup>-

Equipped with an ultra-low vibration (V1) 2.2 kW oil-cooled high-speed motor. It provides 2.2 kW at 2500 min<sup>-1</sup> and covers a wide range from normal grinding to the high-speed range.

Both the spindle and motor use ceramic ball bearings, supporting high RPMs. While enabling wheels with smaller bores, it still provides power for high-speed grinding.


**Canned Software Cycles Provide Simple Operation**—Canned cycles are fixed cycles that give operators full command of the technology without the need to know complicated G-code programming.

32 Amada Lineup of Grinders CNC Grinders 33



#### **ULTRA-LOW VIBRATION SPINDLE MOTOR** FOR ULTRA-MIRROR SURFACE FINISHES

The grinding spindle achieves ultra-mirror surface finishes though a class V1 ultra-low vibration, oil-cooled spindle motor. The motor is equipped with an extra oil bath cooling function as standard equipment, which provides great thermal stability.




#### **HYBRID GUIDE SURFACE WITH GLASS LINEAR SCALE**

This system uses both a linear roller guide slideway (that achieves submicron accuracy) and a hybrid box way for sliding surfaces with enhanced vibration dampening for the vertical and cross axes. A 0.000002" (0.05μm) resolution scale is also included as standard equipment.


Less than 0.000004" (0.1μm) backlash capability (Winstar SP).

- X axis: 0.000026"/0.000027"  $(0.68 \, \mu \text{m}/0.7 \mu \text{m})$
- Y axis: 0.000028"/0.000027"  $(0.71 \, \mu \text{m}/0.7 \mu \text{m})$



#### **HIGH-SPEED, NO-OVERHANG V-V SLIDING SURFACE**

Superior straightness is achieved through the no-overhang design with a wide table base (Winstar SP: 52.75" [1,340 mm], Winstar: 55.11" [1,400 mm]) providing a maximum table stroke of 23.62" (600 mm) for the Winstar SP and 30.70" (780 mm) for the Winstar.




#### **COLUMN TYPE THREE-FACE** INDEPENDENT STRUCTURE

With Amada's unique three-face independent structure (the column moves front-to-back), the vertical, cross, and side-to-side axes are not dynamically affected by other moving axes, thus providing stable processing accuracy.

#### CAE structural analysis by 3D digital design

- Comprehensive analyses were conducted on the displacement of the structure caused by the machine's own weight, table movement, and column movement.
- The results of these analyses led to optimized rib placement, jack placement, and mass balance for repeatable precision.








Table Reciprocation Accuracy (Winstar Sp)



(Winstar Sp)

34 Amada Lineup of Grinders CNC Grinders 35

#### **Grinding Cycle (Standard)**



**Surface grinding**—Traverse grinding is easy when it's digital. The front-back and side-toside positions can be typed as dimensions or input by the electronic teaching button.



**Traverse jump grinding**—This cycle automatically jumps across a space between multiple surfaces on the same height. All surfaces can first be roughed, then all finished for more uniformity. (Optional on Winstar.)


**Equal-depth slot grinding**—Single or multiple



grooves can be easily input and ground. Equal pitch of 999 grooves or unequal pitch of 16 grooves can be set. (Optional on Winstar.)



**Unequal-depth slot grinding**—Complex multiple grooves can be easily input and ground. Fifty grooves of unequal depth/unequal pitch can be set. (Optional on Winstar.)



**Table position setting**—Table stroke position can be set on the screen. For workpieces on the chuck, end stroke positions can be set with the teaching button. The position setting screen enables changing centerline, length, and left and right position.

**Taper mode**—Set the taper angle, turn the handle, and the wheel moves on the angle. When re-grinding workpieces with unknown angles, the angle can be measured with twopoint teaching. Using this function, any angle can be ground or dressed quickly, with no special fixtures.


**R mode (radius)**—Locate the front side and top of a workpiece and set the radius required. When you turn the handle, the wheel grinds a radius profile. The feed speed is controlled by the handle. There is no faster way to grind any radius.

**Taper R**—Grinding/dressing is performed by selecting six types of patterns and simply setting them. By setting rough or fine cut, grinding and wheel forming from a blank are possible.


#### **Grinding Cycle (Optional)**




**Tie bar grinding**—Pitch data for multiple groove grinding can be edited easily. Finishing is done by grinding, leaving several µm each per groove. Creep grinding can also be supported. (Optional on Winstar.)




Pattern grinding—By combining the five most typical patterns, processing of complex shapes can be performed easily. Plunge/traverse can be combined for the most efficient grinding possible. (Optional on Winstar).




Pattern contouring—Contour grinding of simple shapes is as easy as inputting the required dimensions on the screen. Each shape is automatically displayed after input for operator review.




**Contour grinding**—Complex contour grinding can be performed by conversationally inputting figure data. A rough plunge cycle can be created and displayed automatically by the machine. G-code programs can also be uploaded and displayed for grinding.




**Terraced grinding**—Step forms are combined and processed with ease. Forms can be set with five steps and four processes in one pattern. Dressing cycles have been built in, and grinding wheels can be dressed to radius or taper.



Trapezoidal groove grinding-Multiplegroove grinding can be performed on trapezoidal grooves. When the groove dimensions/pitch data are set, wheel forming and processing are performed automatically. Plunge, traverse, and contour grinding can be combined. Rough, medium, and fine processing are performed separately.



**Table stroke**—The speed switching function/ plunge grinding/traverse grinding each have rough, medium, and fine grinding. Table speed and stroke length are adjusted automatically.




**Multi-workpiece function**—By setting multiple workpieces on the chuck, continuous is performed using a tabletop single-point grinding and processing can be performed. A maximum of five types of grinding data can be



#### Air vent grinding (WAPS-WIN required)-

Multiple grooves set on a plate can be processed while determining table strike position. This function processes by loading data created earlier with Amada's WAPS-WIN air vent cycles.



**Hydraulic creep grinding**—Using the table scale feedback, grinding can be performed setting table stroke shift speed to low speed. Both up-cut and down-cut are supported. Groove grinding software or tie bar grinding software is required.

#### **Dress Cycle**



**Straight dress**—Dressing of wheel periphery dresser or high-speed disk dresser. This dressing cycle can be executed almost any time by the operator or a canned cycle.



Pattern dress—Wheel forming is performed using a simple profile dresser, an NC profile dresser, or a high-speed disk dresser. Forms are created by simply imputing the dimensions required for basic shapes on the screen. This dressing cycle can be executed almost any time by the operator or a canned cycle.





**Profile dress**—Wheel forming is performed on various shapes using a simple profile dresser, an NC profile dresser, or a high-speed disk dresser (oval fillister). Rough dress can also be performed. G-code programs can also be uploaded and displayed for dressing.

**Overhead dress**—Wheel periphery dress is performed using an overhead dresser. This dressing cycle can be executed almost anytime by the operator or a canned cycle.

**Grooving dress**—Wheel width is dressed to set values using a lateral face dresser and a high-speed wafer dresser. When the lateral face dresser is used, a back taper can be formed on the wheel.

CNC Grinders 37 36 Amada Lineup of Grinders







Contour Grinding

Angular Groove


Mirror Grinding

## **Unrivaled Grinding Precision by Design**

#### STEP GRINDING ACCURACY

#### **Grinding conditions**

- Grinding wheel: CBN170 Ø7.87" x 0.39" x Ø1.25" (Ø200 mm x 10 mm x Ø31.75 mm)
- Table stroke: 4.72" (120 mm) 57 SPM
- Stock removal: 0.0008" (0.02 mm)
- Grinding processing time: 230 seconds
- Measuring device: Digital length measuring device (Nikon)




CUMULATIVE	PITCH
ERRORS	ERROR
-0.000008"	-0.000008"
(-0.0002 mm)	(-0.0002 mm)
0.00001"	0.000008"
(0.0003 mm)	(0.0002 mm)
0.00002"	
(±0.0005 mm)	
	-0.000008" (-0.0002 mm) 0.00001" (0.0003 mm) 0.00002"

## V GROOVE PITCH GRINDING PRECISION

#### **Grinding conditions**

- Grinding wheel: 89A400I (Tyrolit) 8.07" x
   0.25" (V mountain forming) x Ø1.25" (Ø205 mm x 6.4 mm x Ø31.75 mm)
- Table stroke: 0.79" (20 mm) 150 SPM
- Number of grooves: 18
- Stock removal: 0.019" (0.5 mm)
- Times sparked out: 5
- Grinding processing time: 85 min. (including processing dress one time per groove)
- Measuing device: Non-contact laser 3D measuring device (Mitaka Kohki Co., Ltd.)




	CUMULATIVE	PITCH
	ERRORS	ERROR
MINIMUM	-0.000012"	-0.000016"
VALUE	(-0.0003 mm)	(-0.0004 mm)
MAXIMUM	0.000016"	0.000016"
VALUE	(0.0004 mm)	(0.0004 mm)
MAXIMUM	0.000012"	
ERROR	(±0.00035mm)	

#### MIRROR GRINDING

#### **Grinding conditions**

- Grinding wheel: D2000 Ø7.87" x 0.24" x Ø1.25 (Ø200 mm x 6 mm x Ø31.75 mm)
- Wheel speed: 900 RPM (peripheral speed: 1902 ft/min. (580 m/min.)
- Table stroke: 7.87" (200 mm)
- Table speed: 32.9'/min. (10 m/min.)
- Total grinding: 0.0003" (0.008 mm)
- Rough/fine: 0.00002"/0.000008" (0.0005 mm/0.0002 mm)
- Rough/fine in feed: 0.02"/0.008"
   (0.5 mm/0.2 mm) sync feeding
- Grinding time: 83 min.
- Measuring device: Surface roughness measuring device (Taylor Hobson)




#### **CONTOUR GRINDING**

#### Grinding method

After forming the grindstone corner radius with the rotary dresser, contour grinding is performed.

#### **Grinding conditions**

- Grinding wheel: 1GB100 2 J 6VCSS Ø6.69" x 0.18" x Ø1.25" (Ø170 mm x 4.5 mm x Ø31.75 mm)
- Table stroke: 1.38" (35 mm) 120 SPM
- $\bullet \ {\tt Number \ of \ grinding \ passes: 1} \\$
- Grinding time: 30 min.
- Measuring device: Non-contact laser 3D measuring device (Mitaka Kohki Co., Ltd.)




Machine Sp				WINSTAR SP	WINSTAR
				Simultaneous 2 axis + 1 axis (hydraulic)	Simultaneous 2 axis + 1 axis (hydraulic)
TYPE				Column type	
	Table worki	ng surface (lengi	h x width)	21.6" x 7.8" (550 x 200 mm)	24" x 10.6" (610 x 270 mm)
	Table maxin	num side-to-side	displacement	23.6" (600 mm)	30.7" (780 mm)
	Column max	kimum front-bac	k displacement	9.8" (250 mm)	13.3" (340 mm)
CAPACITY	Spindle heig	ght (spindle C/L	o table)	3.5"~15.7" (90~400 mm)	3.1"~17.7" (80~450 mm)
	Chuck size (	length x width x	height)	19.6" x 7.8" x 3.9" (500 x 200 x 100 mm)	23.6" x 11.8" x 3.9" (600 x 300 x 100 mm)
	Table heigh	t to floor		39.3" (1000 mm)	
	Maximum w	eight (chuck inc	uded)	330 lb (150 kg)	550 lb (250 kg)
		Handle feed	Normal	3.9" (100 mm)	
	Manual	rotation	Slight	0.19" (5 mm)	3.9" (100 mm)
	Manuat	Drive system		Hydraulic servo/mechanical manual pulse handle	Hydraulic servo/ mechanical handle
	Automatic	Feedrate ic	Normal	3~131 ft/m	nin (1~40 m/min)
			Creep feed (OP)	Hydraulic creep Low speed: 0.4"~7.8"/min (10~200 mm/min)	Hydraulic creep Low speed: 0.4"~7.8"/min (10~200 mm/min)
RECIPROCATION (RIGHT TO LEFT)				High speed: 393"/min (10,000 mm/min)	High speed: 393"/min 10,000 mm/min
		Drive system		Servo valve + scale/	Servo valve + scale/
				hydraulic cylinder	hydraulic cylinder
		Reciprocation speed (15 mm stroke)		200 min <sup>-1</sup>	200 min <sup>-1</sup>
	Minimum setting units			0.0004" (0.01 mm)	0.0004" (0.01)
	Position detection/scale resolution			Magnetically guided ABS scale/0.1 μm	Linear scale/1 μm
	Guide surface			W turcite	
		Handle feed Magnification	One rotation	0.0004", 0.004", 0.04", 0.15" (0.01, 0.1, 1.0, 4.0 mm)	0.0004", 0.004", 0.04", 0.15" (0.01, 0.1, 1.0, 10.0 mm)
	Manual	switch, x1, x10, x100, x400, One automatic	One scale	0.000004", 0.00004", 0.0004", 0.0015" (0.0001, 0.001, 0.01, 0.04 mm)	0.000004", 0.00004", 0.0004", 0.0015" (0.0001, 0.001, 0.01, 0.1 mm)
		Drive system		Ball screw/mechanical manual pulse handle	
CROSS				0~15, 39, 78"/min	0~15, 19, 39, 78"/min
LNUJJ	A	F 1 .	Jog feed	(0~400 mm/min, 1000, 2000 mm/min)	(0~400,500,1000,2000 mm/min)
	Automatic	Feedrate	Rapid traverse	157"/min (4000 mm/min)	196"/min (5000 mm/min)
			Grinding feed	0.0004~157"/min (0.1~4000 mm/min)	0.0004~196"/min (0.1~5000 mm/mir
	Minimum se	etting units		0.000010" (0.01 μm)	
		tection/scale res	olution	ABS linear scale/0.05 μm	Linear scale/0.05 μm
	Guide surface			· · · · · · · · · · · · · · · · · · ·	e + slide (hybrid guide)


# **Machine Specifications**


				WINGTIP CP	WINGTAR
				WINSTAR SP	WINSTAR
				Simultaneous 2 axis + 1 axis (hydraulic)	Simultaneous 2 axis + 1 axis (hydraulic)
			One rotation	0.0004", 0.004", 0.04", 0.15" (0.01, 0.1, 1.0, 4.0 mm)	
	Manual	Handle feed	One scale	0.000004", 0.00004", 0.0004", 0.0015" (0.0001, 0.001, 0.01, 0.04 mm)	
		Drive system		Ball screw/mechanical manual pulse handle	
LONGITUDINAL		5 1 .	Jog feed	3.9, 39, 78"/min (100, 1000, 2000 mm/min)	3.9, 7.8, 19, 39"/min (100, 200, 500, 1000 mm/min)
	Automatic	Feedrate	Rapid traverse	78"/min (20	000 mm/min)
			Grinding feed	0.004~19"/min (	0.1~500 mm/min)
	Minimum se	tting units		0.000010	" (0.01 µm)
	Position det	ection/scale re	solution	ABS linear scale /0.05 μm	Linear scale/0.05 μm
	Guide surfac	ce		Linear roller guide +	r slide (hybrid guide)
				Ø8 x 0.25~1 x Ø1.25", Ø2.5~4 x 0.12~0.4 x Ø.875"	Ø10 x 0.25~1 x Ø2" (Ø255 x 6.4~25 x Ø50.8 mm)
WHEEL	Outer diame	Outer diameter x width x bore diameter		(Ø205 x 6.4~25 x Ø31.75, Ø65~100 x 3~10 x Ø22.23 mm)	(\$255 \ 0.4 25 \ \$50.0 \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
	Spindle spe	ed		500~5000 (Inverter)	
				Hydraulic oil 40	Hydraulic oil 100
	Hydraulic oi	l/lubrication oi	l/cooling oil	(tank separated)	(tank separated)
	Tryurautic or	t/tubi ication oi	t/cooting of	Lubrication oil 12	Lubrication oil 20
IVDDAIILIC				(tank separated)	(bed)
HYDRAULIC	Hydraulic/cooling unit capacity (hydraulic oil not included)		city	286 lb (130 kg)	550 lb (250 kg)
	Oil cooler ca	Oil cooler capacity (50/60Hz)		3.7/4.2 HP (2.8/3.2 kW)	5/5.7 HP (3.8/4.3 kW)
	Cooling med	Cooling medium		HCFC R410 (zero for ozone depletion potential)	
	Wheel spind	lle		5 HP (3.7 kW) (oil cooler)	
	Hydraulic pu	ımp		2 HP~4 P (1.5~4 kW-P)	3 HP~4 P (2.2~4 kW-P)
	Cross feed			1.3 HP (1.0 kW)	0.8 HP (0.6 kW)
MOTOR	Longitudinal feed			1.6 HP (1.2 kW)	0.5 HP (0.4 kW)
MOTOR	Reciprocation	on feed		2.4 HP (1.8 kW) (ß12is)	None
	Automatic lu	ubrication pum	)	25W	
	Cooling pump (50/60Hz)			0.4 shared with oil cooling pump (24/28.8L/min <sup>-1</sup> )	0.4 shared with oil cooling pump (24/28.8L/min <sup>-1</sup> )
POWER CAPACIT	Υ			12 kVA	14 kVA
OWER CHINCIT	•		Width	106" (2700 mm)	124" (3150 mm)
ELOOD SDACE					96" (2450 mm)
FLOOR SPACE			Length	82" (2100 mm)	
MACHINE TOTAL	WEIGHT		Height	77" (1975 mm)	82" (2094 mm)
MACHINE TOTAL	WEIGHI			8800 lb (4000 kg)	10,340 lb (4700 kg)

Note: OP indicates an option.


# Winstar SP Floor Space and Travel









# **Winstar Floor Space and Travel**







# **Rotary Grinders**

The high-accuracy ram design and servo motor-driven axes of Amada rotary grinders deliver high-precision grinding and smaller environmental impact. This series guarantees stable grinding through constant grind control.

# SSR5





The proven ram structure of this machine provides enhanced usability and exceptional efficiency while the enhanced feed axis speed shortens setup time. Linear guides on both vertical and horizontal axes improve straightness, while automatic table dressing enhances accuracy. Usability is improved with teaching functions on both the right and left sides, along with a manual pulse handle.





Surface Grinding

#### **SSR5 Features**

Three-Fold Productivity Rate Increase—The Teaching Function—A teaching function on SSR5 has a three-fold productivity advantage both the right and left sides, combined with a compared to a horizontal-axis, square-table surface grinder with equivalent working area.

Low Environmental Load, Non-Hydraulic **Pressure**—Thermal displacement is remarkably reduced by an environmentresponsive structure and non-hydraulic pressure NC specification, which also enables high accuracy.

**Every Spindle Shifts to NC**—Amada's dedicated rotary software allows automatic table dressing and automatic measurement functions.

**Linear Guides**—Both the vertical and horizontal axes feature linear guides for improved straightness.

manual pulse handle, improves usability.

Automatic Table Dressing—Included as standard equipment, automatic table dressing functions enhance dimensional accuracy.

**Servo Controlled Rotary Table**—Enables superior surface finish over entire workpiece face through constant surface speed function.

**Constant Surface Footage**—Table rotation inverter enables synchronization of ram feed and table RPM. Feed speed and ram feed automatically increase to provide optimum surface footage across the face of the part for superior surface finish.

44 Amada Lineup of Grinders Rotary Grinders 45 SSR5 ROTARY SURFACE GRINDER

## **Machine Specifications**

	Diameter of solenoid	chuck valve			20" (508 mm)
CAPACITY		uck upper surface and gnndi	4.9" (125 mm)		
	Maximum swing in ta		21.6" (550 mm)		
		electromagnetic chuck	16.5" (420 mm)		
		on speed range conversion	50~300 min <sup>-1</sup> /21 step		
	Vertical travel distant		7.4" (190 mm)		
	Maximum angle of inc				±3°
			Magnification Off, x0.1, x1, x10, x40	By a rotation	0.0004", 0.004", 0.04", 0.015" (0.01, 0.1, 1.0, 4.0 mm)
ABLE	Manual	Handle feed amount		By a scale	0.000004", 0.00004", 0.0004", 0.0015" (0.0001, 0.001, 0.01, 0.04 mm)
		Jog feed			328, 1640, 3280, 6560 ft/min (100, 500, 1000, 2000 m/min)
		Operation method		Jog lever pulse handle	
		Feedowed		Fast feed	78"/min (2000 mm/min)
	Automatic	Feed speed		Grinding feed	0.004"~39" (0.1~1000 mm/min)
	Minimum setting unit		0.000010" (0.0001 mm)		
	Travel distance		13.1" (335 mm)		
	Manual		Magnification Off, x0.1, x1, x10, x40	By a rotation	0.0004", 0.004", 0.04", 0.015" (0.01, 0.1, 1.0, 4.0 mm [0P])
		Handle feed amount		By a scale	0.000004", 0.00004", 0.0004", 0.0015" (0.0001, 0.001, 0.01, 0.04 mm [0P])
AM		Jog feed			0~31", 39", 78", 157"/min (0~800, 1000, 2000, 4000 mm/min)
		Operation method			Jog lever pulse hande [OP]
		5 1		Fast feed	196"/min (5000 mm/min)
	Automatic	reed speed	Feed speed Grinding fee		0.004~196"/min (0.1~5000 mm/min)
	Minimum setting unit		0.000010" (0.0001 mm)		
RINDING	Outside diameter x w	idth x inside diameter	14" x 1.5" x 5" (355 x 38 x 127 mm)		
HEEL	Rotation speed		0~2500 min <sup>-1</sup>		
	Gnnding wheel axis		10 HP/ 11 P(7.5 /11 kW-P)		
	For table rotation		2.4 HP (1.8 kW)		
LECTRIC EVICE	For vertical feed		1.8 HP (1.4 kW)		
LVICE	For ram actuation		1.6 HP (1.2 kW)		
	Automatic lubrication	ı pump	0.03 HP (25 W)		
	Electric capacity		17 kVA		
	Dimensions (length x	width x height)	83" x 45" x 63" (2120 x 1154 x 1602 mm)		
IMENSIONS / /EIGHT	Required floor space (including dust collec	tion and coolant equipment	110" x 82" (2800 x 2095)		
	Machine total weight		5830 lb (2650 kg)		

# **Control Unit Specifications**

CONTROL UNIT MODEL	F-OiT (FANUC)		
CONTROLLED AXES	Single axis x 2, table rotation axis x 1 (X-axis: cross feed, Z-axis: vertical, B-axis: table rotation)		

#### **Standard Functions**

- Automatic demagnetizing device
- Electromagnetic/permanent magnetic chuck supported
- Simplified permanent chuck demagnetizing function
- Stepless magnetic force adjustment knob
- Electric leakage breaker (sensed current: 30mA)
- 7.2-inch monochrome CD/MDI unit
- Dressing interval (in-grinding dressing)
- Z-axis (vertical) manual handle
- Manual reference point returning
- Stored stroke limit
- Table rotation override 0—100%
- Ram actuation override 0-100%
- Constant table rotation speed control
- Grinding wheel speed S command

- Self-diagnostic function
- Alarm and alarm history display
- Actual speed display
- Clock display
- Current position display
- Servo adjustment image
- Ram position teaching push button
- Operation time/number of parts display
- Chuck workpiece/workpiece reference push button
- $\bullet \ {\sf Relative} \ {\sf coordinate} \ {\sf origin} \ {\sf push} \ {\sf button}$
- End message
- Buzzer (volume adjustable)
- $\bullet \ {\tt Automatic \ table \ dressing \ function}$


#### **Optional Functions**


- X-axis (ram) manual handle
- Handle interruption
- Interruption dressing
- Running timer
- Warning light (1 color [yellow])
- Warning light (3 colors [red, yellow, green])
- Operation time display
- AC100V power outlet (2P)
- Imperial units available

## **Special Accessories**

	Electromagnetic chuck table (ring pole P = 8)
CHIICK	Electromagnetic chuck table (star pole)
CHUCK	Electromagnetic chuck table (star and ring pole)
	Vacuum adsorption chuck device (not including adapter plate)
	Magnetic separator type dust collection and coolant device (150 liters) FW-152-GK
COOLANT EQUIPMENT	Paper and magnetic separator type dust collection and coolant device (150 liters)
EQUIPMENT	Grinding fluid temperature control device
DRESSER	Electric dresser
	Balancing arbor
SPINDLE	Optional grinding wheel flange
	Gnnding wheel width 50 mm
	Balance board
OTHER	Working lamp
	Specified color

#### **External View**






# **CNC Surface Grinders**

With the smallest footprint in their class,
Amada surface grinders can boost your shop's
productivity and efficiency. Integrated operation
handles and a compact control panel allow for
easy accessibility, while processing efficiency is
enhanced by Amada's proven software.



Techster 52 and 52S
High-Capacity, Multi-Purpose
High-Speed CNC Surface Grinders





#### Techster 52 and 52S

**Column**—Built for high rigidity and exceptional straightness, the high column (4" higher than the Meister G3) provides greater flexibility in processing.

**Table**—V-V sliding surface structure provides high-precision operation while the rapid reciprocation rate allows for quick stock removal.

Bed and Saddle—The optimized rib layout and high-rigidity bed structure (with a low center of gravity) were developed through extensive structural analysis. The massive bed and thick saddle support heavier workpieces with outstanding precision and flatness.

**Front-Side Operation**—Axis movement can be controlled from the front of the machine, making column operations easy.

Wheel Spindle—A 5 HP (3.7 kW) spindle motor supports efficient stock removal with a 10" (254 mm) wheel. An 8" (203.2 mm) wheel is optional.

**User-Friendly Control Panel**—The spacesaving control panel with Amada software improves overall efficiency.

- Large table traverse: 23.62" x 9.84" (600 mm x 250 mm)
- Table traverse way: double-V
- Servo valve-controlled traverse drive system

# TECHSTER 52 CONTROL FANUC 32 IB

Two-axis simultaneous plus programmable table. The Meister operating system supports all canned cycle and G-code programming of the Meister series. Supports multiwork canned cycles and all dressing canned cycles.

# **Techster 64 and 64S**


#### Techster 64 and 645 SADDLE TYPE CNC SURFACE GRINDERS





Techster 64 and 64S
Saddle Type Precision
Surface CNC Grinders







Mirror Finish Sample

Slot Grinding Sample Crowning Sample

#### Techster 64 and 64S

**Column**—The unique, isolated three-way sliding column on the Techster 64 and 64S was optimized through structural analysis to deliver maximum performance while requiring minimal floor space.

**Table**—The ball screw drive and no-overhang V-V sliding surface deliver high-precision operation in both high- and low-speed use. The non-hydraulic system is extremely environmentally friendly.

Bed and Saddle—The optimized rib layout and high-rigidity bed structure (with a low center of gravity) were developed through extensive structural analysis. The massive bed and thick saddle support heavier workpieces with outstanding precision and flatness.

**Front-Side Operation**—Axis movement can be controlled from the front of the machine, making column operations easy.

**Wheel Spindle**—The Ø4.93" (100 mm) high-rigidity spindle with quill ensures high-efficiency grinding.


**User-Friendly Control Panel**—The spacesaving control panel with Amada software improves overall efficiency.

# TECHSTER 64 CONTROL FANUC 32 IB

Three- axis control, two-axis simultaneous Meister operating system. Supports all canned cycles and G-code programming of the Meister series. Supports multiwork canned cycles and all dressing canned cycles. Supports creep feed canned cycle, providing high-precision, low-power creep feed.

Techster 52 • 52S • 64 • 64S







CNC Profile Dresser

Simplified Profile Dresser

Automatic Measuring Device

# HIGH-PRECISION SINGLE/TWIN ROTARY DRESSERS

- With a maximum 3,000 RPM, the high-precision single rotary dresser can be used for coarse dressing as well as for finish dressing of simple forms.
- The twin rotary dresser can accommodate two diamond rolls. One can be used for coarse and the other for fine dressing. Dresser width and form can also be changed to widen the scope of form dressing. The dresser spindle is supported on both sides for increased rigidity. It can also accommodate formed diamond rolls for wheel forming in plunge cut operations.



# Delivering a Wide Range of Processing Features and Dressing Systems

CNC Profile Dresser—The built-in servo motor swivels the dresser during wheel forming. With the simultaneous three-axis control of the machine's X and Y, the dresser angle can be kept constant for normal line control. This makes it possible to dress a wheel with only one point of the dresser, providing high-precision profiles.

**Simplified Profile Dresser**—Two forming diamond tools are fitted to perform wheel form dressing at a fixed dresser angle.

#### **Automatic Measuring Device**

(Touch Sensor)—After grinding to the specified dimensions during automatic (canned) cycle operation, this device measures the finished work and reference block, compares the results, and automatically performs follow-up grinding for correction if the workpiece size is out of tolerance. Tolerance for the pass/fail criteria can be set arbitrarily. As the machine's Y-axis is used for measurement, the measuring resolution of this device is 0.000002" (0.05 µm).

## **Machine Specifications**

			TECHSTER 52	TECHSTER 52S	
	Table working surf	ace (L x W)	21.6" x 7.8" (550 x 200 mi	m)	
	Max. longitudinal travel		23.6" (600 mm)		
CAPACITY	Max. cross travel		9.8" (250 mm)		
	Spindle center height from table		19.6" (500 mm)		
	Standard chuck size (L x W x H)		15.7" x 7.8" x 2.7" (400 x 200 x 70 mm)		
TRAVEL	Longitudinal feed		32~98 ft/min (1~30 m/mi	n)	
IKAVEL	Max. no. of recipro	cation (15 mm stroke)	150 min <sup>-1</sup>		
	Rapid cross feed (jog)		0~1300, 1600, 3200 ft/min (0~400, 500, 1000 m/min)	0~3200 ft/min (0~1000 m/min)	
	Handle feed	Per rev.	0.0004", 0.004", 0.04", 0.15" (0.01, 0.1, 1.0, 4.0 mm)	0.004", 0.15" (0.1, 4.0 mm) (OP)	
SADDLE		Per grad.	0.000004", 0.00004", 0.0004", 0.0015" (0.0001, 0.001, 0.01, 0.04 mm)	0.00004", 0.0015" (0.001, 0.04 mm) (OP)	
	Minimum input increment		0.000010" (0.0001 mm)	_	
	Position detection system		Glass scale/0.05 μm (OP)	_	
	Rapid wheel head feed (jog)		3.9, 39"/min (100, 1000 mm/min)	) (2 steps)	
		Per rev.	0.0004", 0.004", 0.04", 0.15" (0.01, 0.	1, 1.0, 4.0 mm)	
WHEEL HEAD		Per grad.	0.000004", 0.00004", 0.0004", 0.0015" (0.0001, 0.001, 0.01, 0.04 mm)		
HEAD	Minimum input increment		0.000010" (0.0001 mm)	Manual 0.000010" (0.0001 mm) Counter 0.000039" (0.001 mm)	
	Position detection system		Linear scale 0.05 μm (OP)	_	
	Size (OD x width x bore)		Ø10 x 0.25~1 x Ø2" (Ø255 x 6.4~25 x Ø50.8 mm)		
WHEEL SPINDLE	Wheel spindle speed		500~5000 min <sup>-1</sup>		
JI INDEL	Motor requirement		5 HP~2 P(3.7~2 kW-P)		
NC CONTROL AXIS		Singly 2 axis	Singly 1 axis		
FLOOR SPACE (W X L X H)		88" x 72"x 78" (2240 x 1840 x 2000 mm)	88" x 69" x 78" (2240 x 1770 x 2000 mm)		
MACHINE NET WEIGHT			5280 lb (2400 kg)		

<sup>\*</sup>The table speed depends on work load on the table.

#### Techster 64 and 64S SADDLE TYPE CNC SURFACE GRINDERS

# **Machine Specifications**

			TECHSTER 64	TECHSTER 64S	
	Table working surfa	ice (L x W)	27" x 15.7" (700 x 400 mi	m)	
	Max. longitudinal travel		30.7" (780 mm)		
APACITY	Max. cross travel		17.7" (450 mm)		
	Spindle center height from table		19.6" (500 mm)		
	Standard chuck size	e (L x W x H)	23.6" x 15.7" x 3.9" (600 x 400 x 100 mm)		
TD AVEL	Longitudinal feed		3.2~98 ft/min (1~30 m/min)		
TRAVEL	Max.no. of reciproc	ation (15 mm stroke)	150 min <sup>-1</sup>		
	Rapid cross feed (jog)		0~1300, 1600, 3200, 6400, 9800 ft/min (0~400, 500, 1000, 2000, 3000 m/min)	16~9800 ft/min (5~3000 m/min) (21 steps)	
	E Handle feed	Per rev.	0.0004", 0.004", 0.04", 0.4" (0.01, 0.1, 1.0, 10.0 mm)	0.0004", 0.004", 0.04", 0.15" (0.01, 0.1, 1.0, 4.0 mm) (0P)	
SADDLE		Per grad.	0.000004", 0.00004", 0.0004", 0.0015" (0.0001, 0.001, 0.01, 10.0 mm)	0.000004", 0.00004", 0.0004", 0.0015 (0.0001, 0.001, 0.01, 0.04 mm) (0P)	
	Minimum input increment		0.0" (0.0001 mm)	_	
	Position detection system		Glass scale/0.05 µm (OP)	_	
	Rapid wheel head feed (jog)		3.9, 39"/min (100, 1000) (2 steps)		
		Per rev.	0.0004", 0.004", 0.04", 0.15" (0.01, 0.1, 1.0, 4.0 mm)		
WHEEL	Handle feed	Per grad.	0.000001", 0.00001", 0.0001", 0.0015" (0.0001, 0.001, 0.01, 0.04 mm)		
HEAD	Minimum input increment		0.000010" (0.0001 mm)	Manual 0.000010" (0.0001 mm) Counter 0.000039" (0.001 mm)	
	Position detection system		Linear scale 0.05 μm (OP)	_	
	Size (OD x width x bore)		Ø14 x 1.5~2 x Ø5" (Ø355 x 38~50 x Ø127 mm)		
WHEEL Spindle	Wheel spindle speed		1500/1800 min <sup>-1</sup> (50/60Hz)		
J. INDLL	Motor requirement		5 HP~4P(3.7~4 kW-P)		
NC CONTROL AXIS		Simultaneously 2 axis	Singly 1 axis		
FLOOR SPACE (W X L X H)		94" x 88" x 81" (2400 x 2240 x 2080 mm)	96" x 85" x 81" (2440 x 2180 x 2080 mm)		
MACHINE NET WEIGHT			8800 lb (4000 kg)		

<sup>\*</sup>The table speed depends on work load on the table.



# Mid-Sized CNC Surface Grinders

Built to deliver consistent repeatability on larger projects, the Techster Series grinders feature high-rigidity beds with low centers of gravity and tables without overhangs, so you can handle heavy, high-accuracy grinding with ease.







Techster Series 84, 104, and 126 Column Type Precision Surface Grinders







Operator Panel

#### **Techster Series Features**

#### **Economy and Ecology**

- The Techster 84. 104, and 126 grinders feature ball screw drive tables as standard. This non-hydraulic drive unit reduces noise and environmental burdens, reducing power consumption while delivering high speed and accuracy for reduced grinding times.
- The vertical axis has a linear guide way with 0.000004" (0.1 $\mu$ m) following for the mirror.
- A powerful 20 HP (15 kW) spindle motor delivers outstanding performance. (Optional on Techster 126.)

#### **Techster Control**


- · Control FANUC Windows interface.
- Three-axis control, two-axis simultaneous.
- Meister operating system-compatible.
- Supports all canned cycles and G-code programming of Meister series.
- Supports multiple work cycles.
- Supports all dressing cycles.
- Supports creep feed canned cycle.
- Provides high precision mid-power creep feed.

#### **Original Designed Structure**


- The high-precision structure has increased mass for high rigidity.
- A long stroke cross axis on a T-type solid bed structure ensures maximum straightness over the life of the machine.
- A high-rigidity, C-type column reduces overhang on the wheel head.
- Table movement is fully guided by V-V slideways.

#### Safe and User-Friendly

- PC-type NC touchscreen.
- Interactive programming software.
- Three types of machine coverings.
- Supports all dressing cycles.



T-Frame Construction



Zero Overhang

#### **Techster Series** COLUMN TYPE PRECISION SURFACE GRINDERS **Techster Series** COLUMN TYPE PRECISION SURFACE GRINDERS







On-Board Measuring Touch Probe




CNC Swiveling Rotary Dresser

## Wide Range of Optional Features


- more efficient grinding.
- A quick and accurate on-board measuring device ensures the tightest tolerances are met.
- An automatic wheel balancer is available for Techster 104 and 126 grinders. This measuring instrument adjusts the balance of the wheel and spindle as an integral unit—perfect balancing improves the ground surface roughness.
- Newly developed original software provides Each available dresser has an automatic dressing cycle program:
  - CNC swivel rotary dresser
  - High-speed rotary dresser
  - Single diamond profile dresser
  - Straight dresser

#### The Techster 126 in Action


The Techster Series' combination of environmental efficiency and grinding accuracy makes mid-sized jobs easy.




Machine Component



Crowning Grinding (Concave Curving)



Crowning Grinding (Slant and Straight)



Programmable Measuring and Auto Re-Grinding



Mirror Finishing Example

#### GRINDING ACCURACY

15 pieces surface grinding	Parallelism 2.0 µm
Longest work surface grinding	Straightness 3.0 µm
Face grinding	Straightness 3.0 μm

60 Amada Lineup of Grinders CNC Mid-Sized Surface Grinders 61

# **Machine Specifications**

			TECHSTER 84	TECHSTER 104	TECHSTER 126	
	Max. longitudinal travel		39.3" (1000 mm)	47.2" (1200 mm)	59" (1500 mm)	
	Max. cross travel		17.7" (450 mm)	18.1" (460 mm)	25.9" (660 mm)	
CAPACITY	Max. spindle center height from table		19.6" (500 mm)	29.5" (750 mm)	33.4" (850 mm)	
	Standard chuck size (L x W x H)		31.4" x 15.7" x 3.9" (800 x 400 x 100 mm)	39.4" x 15.7" x 3.9" (1000 x 400 x 100 mm)	47.2" x 23.6" x 3.9" (1200 x 600 x 100 mm)	
	Longitudinal feed		10~131 ft/min (3~40 m/min.)			
RAVEL	Max. no. of reciprocation (15 mm stroke)		120 min <sup>-1</sup>			
	Traverse guide way/drive		V-V sliding guide way/ball screw direct drive			
	Rapid cross feed (j	og)	0-15, 19, 78, 1	96 ft/min (0~400, 500, 2000, 5000	m/min.)	
	Handla food	Per rev.	0.0004", 0.004", 0.04", 0.4" (0.01, 0.1, 1.0, 10.0 mm)			
ADDLE	Handle feed Per grad.		0.000004", 0.00004", 0.0004", 0.004" (0.0001, 0.001, 0.01, 0.1 mm)			
ADDLE	Minimum input increment		0.000010" (0.0001 mm)			
	Position detection system		Linear scale/deviation: 0.05 μm (OP)			
	Cross guide way/drive		Linear roller guide way/ball screw direct drive			
	Rapid wheel head feed (jog)		3.9, 78"/min (100, 2000 mm/min)			
	Per rev.		0.0004", 0.004", 0.04", 0.157" (0.01, 0.1, 1.0, 4.0 mm)			
HEEL	Handle feed	Per grad.	0.000004", 0.00004", 0.0004", 0.0015" (0.0001, 0.001, 0.01, 0.04 mm)			
EAD	Minimum input increment		0.000010" (0.0001 mm)			
	Position detection system		Linear scale/deviation: 0.05 μm (OP)			
			Linear roller guide way/ball screw direct drive			
	Size (OD x width x bore)		Ø14 x 1.5~2 x Ø5" (Ø355 x 38~50 x Ø127 mm)	Ø14 x 1.5~2 x Ø5" (Ø355 x 38~50 x Ø127 mm)	Ø20 x 38~50 x Ø5" (Ø510 x 38~50 x Ø127 mm)	
WHEEL Spindle	Wheel spindle speed		300~2500 min <sup>-1</sup>	300~2500 min <sup>-1</sup>	300~1500 min <sup>-1</sup>	
PLINDLE	Motor requirement		10HP~4P (7.5~4 kWP)	10HP~4P (7.5~4 kWP) 11~6 kWP (option)	15HP~6P (11~6 kWP) 15~6 kWP (option)	
NC CONTRO	DL AXIS		Simultaneous 2 axis + Table 1 axis			
FLOOR SPA	CE (W X L X H)		133" x 102" x 81" (3380 x 2615 x 2075 mm)	151" x 131" x98" (3850 x 3330 x 2495 mm)	179" x 142" x 109" (4550 x 3630 x 2780 mm)	

<sup>\*</sup>The table speed depends on work load on the table.

## **Dimensions**

	TECHSTER 84	TECHSTER 104	TECHSTER 126
WIDTH	133" (3380 mm)	151" (3850 mm)	179" (4550 mm)
DEPTH	102" (2615 mm)	131" (3330 mm)	142" (3630 mm)
HEIGHT	81" (2075 mm)	98" (2495 mm)	109" (2780 mm)
OPENING		61" (1555 mm)	83" (2115 mm)
TO TOP OF COVER		86" (2190 mm)	98" (2490 mm)
REQUIRED FLOOR PLAN	29ft² (9 m²)	39ft² (12 m²)	52ft² (16 m²)

# **See Amada Grinders at Work**



The AMTA Technical Center was created to provide a unique environment for visitors to experience the latest manufacturing technology in action. This stunning 40,000-square-foot facility houses the latest Amada technology in each product group. Much more than just an exhibit, every machine, automation accessory, and software program in the facility is fully operational and ready to empower customers to solve their most challenging manufacturing applications.

At AMADA MACHINE TOOLS AMERICA, we're committed to

At **AMADA MACHINE TOOLS AMERICA**, we're committed to your success. More than just a provider of precision metalworking solutions, we're a partner who can help you meet the advanced engineering and manufacturing challenges unique to your industry. Together, we can create the right solution to meet your needs today and empower you to build your business for the future.

The information in this catalog is as of August 2013. Specifications and other contents are subject to change without notice.

There may be differences between the specifications described in this catalog and the Amada products actually shipped. Please ask our staff for more detail.

to the Instruction Manual prior to operation.

The cutting performance data in this catalog may be affected by temperature the cutting materials tool.

The products in the catalog may be subject to the provisions of foreign exchange and the Foreign Trade Law. When exporting cargo subject to such controls, permission pursuant to regulation is required. Please contact our business representative in advance when exporting products overseas.

When using our products, safety equipment is required depending on the operational task.

For safe and correct operation, ensure thorough reference to the Instruction Manual prior to operation.

The cutting performance data in this catalog may be affected by temperature, the cutting materials, tool materials, and cutting conditions, etc. Please note that such data are not guaranteed.

#### AMADA MACHINE TOOLS AMERICA, INC.

#### www.amadamt.com

#### MAIN OFFICE

2324 Palmer Drive Schaumburg, IL 60173 tel (847) 285–4800 fax (847) 519–2127

#### BANDSAW AND BLADE BUSINESS

bandsaws@amadamt.com bladeorders@amadamt.com bandsawparts@amadamt.com bandsawservice@amadamt.com

#### **BRANCH OFFICE**

7025 Firestone Blvd Buena Park, CA 90621 tel (714) 739–2111

#### LATHE AND GRINDER BUSINESS

lathes@amadamt.com grinders@amadamt.com latheparts@amadamt.com grinderparts@amadamt.com latheservice@amadamt.com grinderservice@amadamt.com